

CT220 Trailer Door Lock Fitting Instructions

The Bulldog CT220 Trailer Door Lock is intended for fitting to rear door bars of Schmitz Trailers with hidden door bars.



- 1. Position the long arm behind the locking mechanism of the left hand door.
- 2. Slide the short arm over the handle of the right hand door mechanism passing the long arm through the slot.
- 3. Press the lock into the hole to lock the two parts together.
- 4. To remove Container Lock, insert key, rotate half turn, pull on key to withdraw lock, whilst the lock is withdrawn remove the key. The two halves can now be separated.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH. Tel: 01952 728171

Email sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism with WD40 (or equivalent) minimum every four months.