

RORO Skip Lock Fitting Instructions

Fitting



1. Place the cover over the lifting point of the skip.



2. With the lock bolt in the unlocked position, insert it through the cover and lock it into the receiver by turning the key a quarter turn clockwise. Remove the kev.



3. To unlock, insert the key turn it a quarter turn anti clockwise and withdraw the lock from the cover.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot quarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH. IMPORTANT - To ensure free movement of the lock, Tel: 01952 728171

Email: sales@bulldogsecure.com www.bulldogsecure.com

Lock Lubrication.

spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.